

Sofa Care & Comfort Guide

Thank you for purchasing your new sofa. We've put together this guide to help you understand what to expect when your sofa arrives, how to care for it, and how to avoid common issues. Please take a few moments to read through to get the most from your sofa and reduce the need for aftercare.

New Sofa: What You Should Know

Your new sofa may look or feel slightly different than expected when first unpacked. That's completely normal. Here are the most common things to expect in the first days — and how to handle them:

Why Your Sofa Feels Firm at First

New cushions often feel firmer than expected. We use high-density foam that softens over time for longevity and durability. With regular use, the foam adjusts and becomes more comfortable within two to six weeks depending on how often it is used. Sitting across different areas helps this process happen evenly.

Why Armrests or Edges May Look Flat/Squashed

Padding around the arms, backrest, or seat edges might look slightly dented or uneven right after unpacking. This is a result of protective packaging during transit. These areas will return to their proper shape within a few weeks. Gently patting & massaging the area can help it recover faster.

First Days: Fabric Fit and Cushion Shape

Cushions may look misshapen, and fabric might appear wrinkled or loose at first. As the foam expands, the fabric will relax and smooth out. Hand-smoothing and occasional fluffing will speed up the settling process. If your model has removable cushion covers, they can be unzipped and refilled over time to restore volume and comfort.

General Care Guidelines

To maintain your sofa's appearance and condition, vacuum fabric surfaces regularly using an upholstery attachment. Keep the sofa out of direct sunlight and away from strong heat sources to prevent fading, drying, or material warping. Only use cleaning agents that are suitable for the specific fabric type, and always follow the care label instructions.


Warranty Coverage and Exclusions

Your sofa is covered against manufacturing defects under normal residential use. However, the following types of damage or issues fall outside the scope of warranty coverage and will not be accepted as valid claims:

- Normal wear and tear, including gradual softening of foam, flattening of fillings, and pilling of fabric
- Misuse or mishandling, including jumping or standing on the sofa, or sitting on armrests or backrests
- Pet-related damage such as scratches, chewing, or soiling
- Exposure to outdoor conditions, moisture, or direct sunlight, unless the product is specifically rated for such use
- Use of inappropriate cleaning products or methods
- Placing hot items (such as laptops or heating pads) directly on upholstered surfaces
- Improper assembly that leads to instability, frame damage, or misalignment
- Structural modifications or unauthorised repairs

ASSEMBLY INSTRUCTIONS

———— Thank you for choosing our product!



1. Suggestions before starting assembly: Read the instructions from beginning to end and prepare 2-4 adults for assembly, depending on the size of the product. Do not assemble directly on the floor or carpet, assemble on a clean non-abrasive surface (e.g. packing foam). Save all packaging until complete.

2. Return Policy: Do not return to the store! Skip the return process and contact us directly for your after-sales service. Let us know the details of your order and any problems you encounter and we will be happy to help you with solutions or answer any questions you may have.

3. Assembly precautions: After opening the package, remove all internal hardware packaging and take out the parts. Then refer to the manual to count the parts and quantity and make sure no parts are missing. Some critical parts of your product may be stored and hidden in other parts. Please open any storage compartment with a zipper or hook and loop and remove all parts. (Example: the cushions and legs are stored at the bottom of the sofa). If you find any parts missing, first check carefully that the box is complete to see if parts have spilled out and been scattered inside the carton, or if the carton has been broken

causing parts to be missing. If you encounter any problems during the assembly process and find that you can not continue, please rest assured that we will help you solve the problem as soon as possible. Simply store all parts of your product in a safe place and contact us immediately so that we can help you further.










4. Care and Maintenance: Do not place hot objects directly on the surface of the furniture. Do not clean furniture with harsh cleaners or polishes. Do not leave furniture in direct sunlight. Do not place furniture near heating or cooling vents. Do not write on furniture without a pad to protect the surface. Do not leave furniture outdoors, for indoor use only. Do not use for commercial purposes, for residential use only. Stains can be removed with a mild soap solution and a damp cloth. Children should not climb or jump on furniture. Use a clean, colorless, lint-free cloth to remove dust.

Caution!


This product contains small parts. Please make sure they are kept away from children when installing.

Do not use power tools to assemble furniture. Power tools may peel or damage parts.


PART LIST:

A		H	
1 PC		2 PCS	
B		I	
1 PC		4 PCS	
C		J	
1 PC		12 PCS	
D		K	
1 PC		2 PCS	
E		L	
1 PC		4 PCS	
F		M	
1 PC		1 PC	
G			
3 PCS			


Note: Some parts are packaged in the following ways, please take them out before installation.




Step 1:




Step 2:




Step 3:




Step 4:




Step 5:




Step 6:





Step 7:




NOTE 1:



NOTE 2:







Complete











Packing List

BOX 2-1

	B×1		F×1
	E×1		G×1

BOX 2-2

	A×1		I×4
	C×1		J×12
	D×1		K×2
	G×2		L×4
	H×2		M×1